



Clam art nr: 75401-75423
Installationsanvisning/Assembly instruction

 Armaturen ska monteras av behörig installatör.

Viktigt: Bryt spänningen före installation.

1. Försäkra er om att spänning och frekvens på armaturen och nätet överensstämmer.
2. Lossa hylsan(A) och för ner takkoppen(B).
3. Fäst armaturen i taket i de tre uppfästningshålén.
4. Anslut nätledningen till kopplingsplinten.
5. Montera dit takkoppen igen.

Montering av glas: Enklast är att montera glaset efter att armaturen är upphängd. Trä ner vajrarna genom överdelens hål(C). Skruva bort täckmuttern(D) trä sedan vajern genom vajerlåset. Ställ in lämplig höjd och klipp där efter av vajern. Skruva dit täckmuttern igen.
(Tips: Armaturen behöver inte hänga rakt. Testa att ha olika längder på vajrarna.)

Vid byte av ljuskällor: Lyft upp överdelen(E)

Important: Switch off the mains voltage.

1. Ensure that voltage and Hz on the fixture and mains voltage are the same.
2. Unscrew the nut(A) and pull down the ceiling cup(B).
3. Fix the fitting in the ceiling through the holes.
4. Connect cable to the terminal block.
5. Fit up the ceiling cup.

Fix the glass: We recommend to mount the glass when the fixture is hanged. Slip the wire through the holes(C). Unscrew the cover nut(D). Slip the wire trough the wire lock. Adjust the wire and cut the wires.
(Tip: It is not necessary to hang the fixture straight. Test different lengths on wires.

When changing light source: Lift part(E).

